

Analog output properties

- objectName
- objectType
- presentValue
- description
- deviceType
- statusFlags
- eventState
- reliability
- outOfService
- updateInterval
- units
- minPresValue
- maxPresValue
- resolution
- covIncrement
- priorityArray
- relinquishDefault
- timeDelay
- notificationClass
- highLimit
- lowLimit
- deadband
- limitEnable
- eventEnable
- acknowledgedTransitions
- notifyType
- eventTimeStamps

Permanentný odkaz:

<https://wiki.apli.sk/doku.php?id=sk:blacky-ao&rev=1490984089>

