Driver M-bus

Description

- Protocol implementation according to EN 13757-2 and EN 13757-3
- connection of M-bus devices through local M-Bus converter
- connection of M-bus devices through unlimited number of remote M-Bus/TCP converters
- driver for reading M-Bus devices uses primary addressing
- configuring basic M-Bus device parameters:
 - primary address
 - secondary address
 - transfer speed
 - reading basic parameters:
 - manufacturer
 - medium
 - primary address
 - secondary address
- integrated M-Bus telegram analyzer, which can be used to create read profile from unknown device
- creating M-Bus telegram with command (e.g. command to disable button) and its sending through associated Bacnet point
- it is possible to assign mathematical operations to each M-Bus point:
 - $\circ\,$ add value
 - $\circ~$ substract value
 - multiply by value
 - $\circ\,$ divide by value
 - $\,\circ\,$ mathematical operations are computed with double precision float numbers
- each M-bus device has created point containing state value of last reading
- active reading profile can be tested and its return results displayed
- Bacnet point for manual start of M-Bus devices reading
- virtual M-bus/TCP converter:
 - allows direct device configuration with manufacturers software on device
 - $\circ\,$ slave mode paralel sensor reading with packet insertion from TCP client
 - $\circ\,$ master mód disables devices reading and master client gains exclusive access to M-Bus converter

Knowledge of M-bus protocol is required to work with this driver.

Virtual gateway M-bus/TCP

Enables direct configuration of M-Bus devices with manufacturers software.

Virtual COM port emulator is requried to use this function. For Windows we recommend to use VSPE, 32-bit version is free.

Master connection

Enables exclusive access to M-Bus converter. All M-Bus functions of M-Bus/Bacnet converter are disabled while connection is active.

Connection is established with **TCP** protocol on port **2001**.

Slave connection

Retains M-bus/Bacnet converter functions and adds received telegrams from TCP client to telegrams sent to converters software. Responses on these telegrams are returned on open TCP connection.

Connection is established with **TCP** protocol on port **2000**.

Bacnet implementation

M-bus	Bacnet
Value from telegram	AnalogInput
Manual M-bus read	BinaryValue
State of last read	AnalogInput
M-bus command	AnalogValue

Properties:

- objectName
- objectType
- presentValue
- statusFlags
- outOfService
- covIncrement
- priorityArray
- relinquishDefault
- units

Values of state point of M-bus device

- **0** OK
- 1 No response
- 2 Failed to open port
- 3 CRC error
- 4 Failed to decode telegram
- Writing any value through Bacnet starts manual reading of device

Bacnet point of M-bus command

Written value will be used as M-bus address when command is sent to M-Bus.

Bacnet point for manual devices reading

Writing any value will start manual reading of all devices.

Driver settings

Communication speed:

Transfer speed of local port.

COM port:

Selection of local COM port.

Manual reading - point name:

Name of Bacnet point to start devices reading. Reading starts after writing any value to this Bacnet point.

Status of master M-Bus connection:

Displays status of master M-Bus connection.

M-Bus functions of converter are blocked while connection is active.

Disconnect master client

Disconnects master client.

Virtual COM ports

Virtual ports manager.

Button	Description	
×	Save settings	
×	Undo	
×	Add virtual COM port	
×	Delete selected	
×	Check availability of virtual ports	

Only TCP connection is supported currently.

M-bus devices settings

×

×

Port configuration

Transfer speed Currently set transfer speed of local M-Bus converter. Changes are applied

immediately. Uarning! Transfer speed also affects reading algorithm of M-bus/Bacnet driver.

Select COM port

Selection of used port for devices configuration

Commands sending

Primary address Primary address of configured device:

- 254 command for all devices (broadcast)
- 253 command for secondary addressed device through Slave select

snd_nke
Sends telegram snd_nke
req_ud2
Sends telegram req_ud2
Slave select
Select device with secondary address
Change primary address
Changes primary address of device
Change secondary address
Change secondary address
Change transfer speed
Changes transfer speed

Decoded req_ud2 response

In this part will be displayed decoded response to req_ud2 telegram.

M-bus device profiles

Profile is template configuration for converting M-Bus telegrams to Bacnet points.

×

Editor for M-bus device profiles

×

×

In top part of the screen is located list of current profiles.

Button	Description
×	Create profile
×	Create profile from M-Bus device
×	Delete selected profiles
×	Save profile settings. Warning, only this option saves changes permanently to file. Other save options will save changes in memory. Remember to use this option at the end of your work!
×	Undo
×	Test profile on M-Bus device

Editor for M-bus device profile

Bacnet object name:

Name of M-Bus status point on Bacnet

Symbol @ will be replaced with given text on profile upload to M-Bus read configuration.

REQ_UD2:

"C Field" of sent telegram.

Timeout [s]:

Telegram reading timeout in seconds.

Data from TCP converters will be processed after time limit. M-bus device needs to send all data or CRC errors can occur.

Description:

Notes:

User description and notes.

Button Description

×	Save settings
×	Undo

List of telegram entries

These entries are exported as Bacnet points

Button	Description	
×	Add entry	
×	Delete selected entries	
×	Save entries settings	
×	Undo	

M-Bus telegram records editor

Bacnet object name:

Name of M-Bus point on Bacnet.

Symbol @ will be replaced with given text on profile upload to M-Bus read configuration.

×

Bacnet units:

Units accessible through Bacnet

Telegram number:

Position in telegram:

Informative value on automatic read from M-Bus device

VIF+VIFE:

VIF+VIFE value

DIF+DIFE:

DIF+DIFE value

Search by:

Entry in telegram is searched by VIF+VIFE, or by VIF+VIFE and at the same time by DIF+DIFE. You can find more informations about structure of M-Bus telegram here.

Mathematical functions and their values

Allows modification of decoded values before they are written to Bacnet point.

Button	Description	
×	Save settings	
×	Undo	

Telegram data

Hexadecimal representation of recieved telegram on automatic profile generation.

Generate profile from M-Bus device

×

Button	Description	
×	Read M-Bus device on specified COM port and req_ud2	
×	Generate profile from received data	
×	Cancel profile generation	

Test profile on M-Bus device

×

Button	Description
×	Test profile on specified COM port and req_ud2
×	Close window

M-Bus device settings

×

×

×

M-Bus devices editor

In top part of the screen is located list of currently configured devices.

Button	Description
×	Create M-Bus device
×	Create M-Bus device from profile
×	Update selected device from profile
×	Remove selected devices
×	Save devices settings. Warning, only this option saves changes permanently to file. Other save options will save changes in memory. Remember to use this option at the end of your work!
×	Undo
×	Test current settings on M-Bus device.

M-Bus device editor

Primary address:

Primary address of M-Bus device

Bacnet object name:

Name of M-Bus status point in Bacnet

REQ_UD2:

"C Field" of send telegram.

COM port selection:

Port of connected device

Timeout [s]:

Telegram reading time limit in seconds.

Data from TCP converters will be processed after time limit. M-bus device needs to send all data or CRC errors can occur.

Button Descrition

Save settingsUndo

List of telegram entries

These entries are exported as Bacnet points

Button	Descrition	
×	Add entry	
×	Delete selected entries	
×	Save entries settings	
×	Undo	

×

M-Bus telegram entry editor

Name of Bacnet point:

Name of M-Bus entry on Bacnet.

Bacnet units:

Units accessible from Bacnet

VIF+VIFE:

VIF+VIFE value

DIF+DIFE:

DIF+DIFE value

Search by:

Entry in telegram is searched by VIF+VIFE, or by VIF+VIFE and at the same time by DIF+DIFE. You can find more informations about structure of M-Bus telegram here.

Mathematical functions and their values

Allows modification of decoded values before they are written to Bacnet point.

Button	Description	
×	Save settings	
×	Undo	

M-bus commands settings

×

M-bus commands editor

In top part of the screen is located list of current commands.

Button	Description
×	Add M-Bus command
×	Add predefined command
Delete selected commands	
×	Save commands configuration
×	Undo

M-bus command editor

Bacnet object name:

Name of the Bacnet object **Enabled** Exports command to Bacnet **COM port:** COM port on which will be command sent ×

×

×

Timeout [s] Response time limit, used to clear RX buffer <C> Telegrams "C-field" <CI> Telegrams "Cl-field" <DATA>

Hexadecimal representation of telegrams data

Telegram address will be included from defined value in Bacnet object. Length and CRC will be calculated before telegram is sent.

Button	Description
×	Save settings
×	Undo

Permanentný odkaz: https://wiki.apli.sk/doku.php?id=en:blacky-mbus&rev=1493126111

